



# MG75S HE有线键盘用户手册

User Manual

Benutzerhandbuch

快速开始指南 ▶


Quick Guide

# 感谢您购买及使用本产品



为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

## 产品概览



## 系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

## 安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

## 独立指示灯

状态	指示灯位置	指示方式
舒适模式	1键	白灯常亮1s随背光
灵敏模式	2键	白灯常亮1s随背光
游戏模式	3键	白灯常亮1s随背光
自定义模式	4键	白灯常亮1s随背光
Caps	独立指示灯1	白灯常亮
系统指示灯	独立指示灯2	白灯常亮
锁WIN	独立指示灯3	白光常亮

## MG75S HE 组合键功能



Fn+	F1	=	我的电脑
	F2		电子邮件
	F3		Windows搜索
	F4		浏览器主页
	F5		多媒体播放器

Fn+	F6	=	播放 / 暂停
	F7		上一首
	F8		下一首
	P		PrtSc
	C		计算器

Fn+	I	=	Insert
	M		静音
	<		音量减小
	>		音量增加
	W		将WASD与 ↑ ↓ ← → 键对调

## 调整按键行程快捷键


**Fn+1** 舒适模式 - 行程按下2mm，抬起2mm

**Fn+2** 灵敏模式 - 行程按下0.5mm，抬起2mm

**Fn+3** 游戏模式 - 行程按下0.5mm，抬起2mm+火力模式

**Fn+4** 自定义模式 - 驱动自定义轴行程通道，行程按下2mm，抬起2mm

## MG75S HE 系统功能 (Windows)



**锁Win键**

Fn + 左Win


**恢复出厂设置**

长按 Fn + ~ 5秒

**切换成菜单键**


长按Fn + 右Ctrl 3秒

## MG75S HE 系统功能 (Mac)



F1	降低显示屏亮度	F7	上一曲	F11	调低音量
F2	增加显示屏亮度	F8	播放/暂停	F12	调高音量
F3	开放任务控制	F9	下一曲	左Win	Option
F4	呼出Siri	F10	静音	左Alt	Command
右Alt	Command	Fn + (F1~12)		F1 ~ F12	

## MG75S HE 灯光调节



Fn+-	灯光速度变慢	Fn+Home	常亮、涟漪、如影随形、川流不息、流星
Fn+=	灯光速度变快	Fn+PgUp	繁星点点、霓虹、光波、层出不穷、彩泉涌动
Fn+↑	灯光变亮	Fn+End	呼吸、极光、正弦波、雨滴、峰回路转
Fn+↓	灯光变暗	Fn+PgDn	斜风细雨、踏雪无痕、聚合、一石二鸟、百花争艳
Fn+←	灯光方向向左	Fn+\	切换背光致7种单色+RGB循环
Fn+→	灯光方向向右	Fn+L	灯光关闭/开启



## 按键/灯光自定义说明和调用说明

1. 键盘按键/灯光自定义可配合驱动进行
2. 键盘灯光可搭配驱动实现音乐律动
3. 请在我司官网下载“MonsGeek\_setup”驱动
4. 驱动下载地址[www.monsgeek.cn](http://www.monsgeek.cn)

## MONSGEEK保修和服务声明

1. MONSGEEK为中国大陆的客户提供一年保修。对于其他地区，请联系您的卖家（MonsGeek分销商）以了解具体的保修政策。
2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，MonsGeek也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
3. 由于私自拆卸产品、使用不当和安装不当而导致的缺陷不在保修范围内。
4. 官方售后服务时间为每周一至周五上午10:00至下午18:00，节假日以国家法定节假日休息为准。
5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司

地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话：0755-23216420

网址：[www.monsgeek.cn](http://www.monsgeek.cn)

产地：中国·深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China




中国制造 / Made in China

**注意  
事项**

人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品，请按照电子产品保护方式爱惜使用。

To provide you with a better user experience, please read this manual carefully before using the product.

## Packing List



## Minimum System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

## Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB-A port to start using it.

## LED Indicator Overview

Description	Position	Indicator
Comfort Mode	LED for Key 1	White light stays on for 1 seconds and then follow the backlit
Sensitive Mode	LED for Key 2	White light stays on for 1 seconds and then follow the backlit
Game Mode	LED for Key 3	White light stays on for 1 seconds and then follow the backlit
Custom Mode	LED for Key 4	White light stays on for 1 seconds and then follow the backlit
Caps	Independent LED Indicator 1	Steady white
Mac OSX Mode	Independent LED Indicator 2	Steady white
Lock Win	Independent LED Indicator 3	Steady white

## MG75S HE HotKeys



Fn+	F1	My Computer
	F2	E-mail
	F3	= Windows Search
	F4	Browser Homepage
	F5	Multimedia Player


Fn+	F6	Play/Pause
	F7	Previous Song
	F8	= Next Song
	P	Print SCR
	C	Calculator

Fn+	I	Insert
	M	Mute
	<	= Decrease Volume
	>	Increase Volume
	W	Swap WASD with ↑ ↓ ← →

## Shortcuts to Adjust Travel Distance

Fn+1	Comfort Mode - Comfort Mode - Actuation Point = 2mm
Fn+2	Sensitive Mode - Actuation Point = 0,5mm, Reset Point = 2mm
Fn+3	Game Mode - Actuation Point = 0,5mm + Rapid Trigger 0,1mm Sensitivity
Fn+4	Custom Mode - Customize Switch Actuation Point through Akko Cloud Driver

## MG75S HE System Commands (Windows)




<b>Lock Windows Key</b>
Press Fn and Left Win Key

<b>Restore Factory Settings</b>
Hold down Fn and press ~ Key for 5S


<b>Revert Ctrl into Menu Key</b>
Hold down Fn and press Right Ctrl Key for 3S

## MG75S HE System Commands (Mac)



F1	Decrease display brightness	F7	Skip back (Audio)	F11	Volume down
F2	Increase display brightness	F8	Pause/Play (Audio)	F12	Volume up
F3	Open mission control	F9	Skip forward (Audio)	Left Win	Option
F4	Activate Siri	F10	Mute	Left Alt	Command
Right Alt	Command	<b>Fn + (F1-12)</b>		F1 ~ F12	

## MG75S HE Backlight Settings



Fn+-	Slower Animation	Fn+Home	Effect1, Effect2, Effect3, Effect4, Effect5
Fn+=	Faster Animation	Fn+PgUp	Effect6, Effect7, Effect8, Effect9, Effect10
Fn+↑	Bright	Fn+End	Effect11, Effect12, Effect13, Effect14, Effect15
Fn+↓	Dim	Fn+PgDn	Effect16, Effect17, Effect18, Effect19, Effect20
Fn+←	Set animation direction to left	Fn+\	This shortcut allows you to set the backlight color to 7 single color with RGB loop effect
Fn+→	Set animation direction to right	Fn+L	Light Off/On

# Key Remapping/LED Effects/Customized Actuation Setup Instruction

1. Fundamental features such as key/lighting effects customization can be programmed with MonsGeek Driver.
2. Hall effect switches related functions are programmable in MonsGeek Driver. Please check for the latest firmware and driver for optimized gaming experiences and new features.
3. Users can download the driver via [www.monsgeek.com](http://www.monsgeek.com)

## MONGEEK Warranty and Service Statement

1. MONGEEK provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (MonsGeek distributor) for specific warranty policy.
2. If the warranty window expires, customers need to pay for repairs. MONGEEK will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.
3. Dissembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchon Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: [www.monsgeek.com](http://www.monsgeek.com)

Origin: Shenzhen, China



中国制造 / Made in China

### Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.

 MONSGEEK